


# **MAINTENANCE INFORMATION FOR THE FUNCTION GENERATOR NO. 40600/40620**



**ENERGY CONCEPTS, INC. Eci**






# INTRODUCTION

This manual provides maintenance information for the Energy Concepts FUNCTION GENERATOR, Model No. 40600-40620. Read this manual thoroughly before you use the unit. Additional information for the unit is also included in the OPERATION INFORMATION FOR THE FUNCTION GENERATOR, manual number 40609.

Each new unit has been thoroughly inspected, adjusted, and tested before shipment from the factory. As soon as you receive the unit, inspect the shipping carton and the equipment for damage. Report any visible damage to your local carrier for repair or replacement. If the unit does not function properly, or if you have any questions, contact the Energy Concepts Service Center.

This instrument is backed by more than 60 years of experience in designing and manufacturing educational and practical training equipment. Every effort has been made to design into each unit a maximum degree of dependability, accuracy, and durability. New products are being designed constantly to meet the needs of both education and the service industries. We welcome comments that you may have about our products or test equipment.

It is both a privilege and a pleasure to continue serving you.



Richard E. Gibbons  
President, Energy Concepts, Inc.

**COPYRIGHT© 1996 BY ENERGY CONCEPTS, INC.**

All rights reserved. No part of this publication may be reproduced or reprinted in any form, without written permission of Energy Concepts, Inc., 595 Bond St., Lincolnshire, IL 60069.

Printed in the United States of America, 1998, 1996.

ISBN: 1-55756-077-3



# MAINTENANCE INFORMATION

## SECTION 1

### GENERAL

The Energy Concepts Function Generator is a precision instrument which, when used and maintained properly, will provide years of trouble-free operation. However, when service is required, the chassis parts and circuit board components are easily accessible and clearly identified for convenience in troubleshooting.

#### NOTE

ALL TROUBLESHOOTING, COMPONENT REPLACEMENT, AND ALIGNMENT OF THIS INSTRUMENT SHOULD BE PERFORMED BY AUTHORIZED, QUALIFIED SERVICE PERSONNEL ONLY.



### CASE REMOVAL

1. Disconnect the AC power cable from the AC source. Remove all test leads from the front panel.
2. Use a  $\frac{9}{64}$ " Allen wrench to remove the four Allen-head cap screws from the end caps.
3. Lay the end caps and screws to one side.
4. If the unit is not in a portable case, it may be held by a screw on the bottom of the shelf. Proceed to step 7.
5. Use a pliers to remove the strain relief that holds the power cord on the back panel.
6. Use a #1 Phillips screwdriver to remove the strain relief plate.
7. Use a  $\frac{1}{4}$ " bladed screwdriver to remove two screws from the bottom.
8. Remove the unit from the case by sliding the unit forward.

### CIRCUIT BOARD COMPONENT IDENTIFICATION

Figure 1, on the following page, shows the electrical components mounted on the top of the circuit board. It will aid in locating and identifying the various mounted components. The foil on the bottom of the circuit board is also shown (superimposed) to aid the servicepeople in visualizing the electrical connections.







## **CIRCUIT DESCRIPTION**

Figure 3, on the following page, is a simplified functional diagram of the Function Generator. It is included to show how the individual output signals are developed. A complete schematic diagram is given in the back of the Maintenance Manual. The component numbers given in Figure 2 are correlated to the schematic diagram.

## **BASIC WAVEFORMS**

The Function Generator is built around a basic circuit consisting of an integrator (U105), a buffer (U106), and a level detector (U107). The integrator consists of timing resistors, timing capacitors, and an Operational Transconductance Amplifier (OTA), a special type of OP-Amp, whose output gain is controlled by the current input at its pin 5. This input will set up the charging current to the timing caps. If we assume a positive input at U105, then the timing capacitor will charge positively toward +15V. This voltage is buffered by U106 and fed to U107 through a voltage divider. The trip point of U107 is set up by D104 and D105. As the voltage set up by voltage divider R109 and R110 crosses the trip point, U107 changes state. This reverses the voltage input at U105 and causes the charging current at the timing caps to reverse. This charging and discharging cycle results in a triangular waveform. The level changing output of U107 is a low level squarewave.

## **FREQUENCY CONTROL**

The level of the current applied to pin 5 of U105 is controlled by FREQUENCY ADJUST control R1. The voltage appearing at the wiper of R1 is buffered by one half of U109 and fed to R132 and the other half of U109, which is set up as a current buffer. The current output is in direct proportion to the voltage input at R132. By varying the voltage to R132 by R1, the current input to pin 5 of U105 and its output will vary. This changing output varies the time it takes for the timing capacitor to charge and discharge, thus changing the frequency of the signal out. By switching in different values of timing capacitors, the range in frequency is changed. Trimming of each frequency range is accomplished by timing resistors R158 to R165.

The input to the current buffer U109 is a summing junction where the voltages from R1 and the VCG input are summed up to control the frequency of the signal out. If the FREQUENCY ADJUST control is set to the low frequency side of the dial, a +10VDC input at VCG input will cause an increase in frequency by a factor of 30.






FIGURE 3, Simplified Block Diagram



## **SQUAREWAVE/TTL**

The low level squarewave output of U107 is fed to U108, a dual line receiver, which generates two separate TTL level signals proportional in frequency to the low level input signal.

One of the TTL signals developed by U108 is sent to a shaping network, which changes the +5V TTL level signal to a  $\pm 15V_{P-P}$  squarewave. This signal is sent to the function switches. The squarewave function switch disables the output of U108, which generates the squarewave, so that there is no signal developed until the switch is activated. This is done to reduce crosstalk into the sinewave.

The second TTL signal is sent to its protection network (R210, D106, D107) and then to the TTL output connector.

## **TRIANGLE/SINE**

The buffered triangle wave output from U106, aside from being fed to U107, is also fed to U110. At U110, the signal is buffered and sent to the function switches and to the sine shaping circuit U111. U111, a low capacitance diode array, along with associated biasing resistors, set up different break points, which reshape the signal in. With the input being a triangle wave, the output will be a sinewave.

## **MODULATOR**

The sinewave output of U111 is fed to U112, an Operational Transconductance Amplifier (OTA), a special Op-Amp, whose output gain is controlled by the input at its pin 5. With no signal present at the EXT MOD IN connector, and the MOD switch in the OFF position, the gain of U112 is controlled strictly by R148.

A signal input at the EXT MOD IN/1 kHz OUT connector will be AC coupled to pin 5 of U112 where it will interact with the gain setting of R148 in proportion to its signal level, thus, modulating the output of U112. Another way that the output of U112 can be modulated is internal. When the MOD switch is in the ON position, it turns ON a 1 kHz phase shift oscillator, whose output is AC coupled and fed to pin 5 U112. This 1 kHz signal is also fed to the EXT MOD/1 kHz OUT connector. The output of U112 is fed to the function switches.

## **FUNCTION SWITCHES/AMPLIFIERS**

All the signals present at the function switches can be individually selected and fed to pre-amp U113 where initial amplification takes place. The output of the pre-amp is fed to AMPLITUDE ADJ control R177. R177 controls the amount of signal fed to the main amplifier, composed of U114 and associated transistors, where final amplification takes place. Varying R177 will change the signal level from near zero to about  $20 V_{P-P}$  out.

## **DC OFFSET**

DC offset is selected by S3. In the OFF mode, DC offset is controlled by R185, an internal trimmer, which is adjusted for zero DC offset. In the ON mode, DC offset is controlled by OFFSET control R127, which allows a control range of  $\pm 10V$  of DC offset on the output signal.



## PROTECTION CIRCUITS

Figure 4 is a simplified functional diagram of the Protection Circuits. It is included to show how the individual overload signals are developed. A complete schematic diagram is given in the back of the Maintenance Manual. The component numbers given in Figure 4 are correlated to the schematic diagram.




FIGURE 4, Simplified Diagram of Protection Circuits

The protection circuit consists of a Positive Temperature Coefficient (PTC) resistor, a device whose resistance increases with an increase in temperature, and a high power crowbar. When a voltage source higher than  $40V_{P-P}$  is connected to either HI or LO output connectors, the crowbar will turn ON and shunt the external source to ground. With current flowing through the crowbar, higher than normal current flows through the PTC causing it to rise in temperature and to continue rising until it reaches its temperature trip point. Once the PTC reaches the trip point, its resistance will increase rapidly to a high point, and for all practical purposes the external voltage source will be isolated from the internal circuitry. To return to normal operation, the overload condition must be removed from the connectors and the PTC must be allowed to cool long enough until it drops below its temperature trip point. Protection for the TTL OUTPUT connector is the same as previously described. Only the external voltage source can be as low as + 8V and the crowbar consists of a single zener diode, D101.

Protection of the other two connectors consists of series limiting resistors.



## OVERLOAD INDICATOR

Each of the three PTC's in the protection circuit has a thermistor attached to it which is electrically insulated, but thermally coupled to the PTC. As the temperature of the PTC increases because of an overload condition, the resistance of the thermistor decreases. Each thermistor is connected to a voltage comparator, U115, set to detect a decrease in resistance below a set value, which corresponds to the trip point of the PTC. The outputs of the comparators are connected to a flashing LED circuit consisting of Q112, R301, D301, and D302. Under normal conditions, the outputs of the comparators are high, turning on transistor Q112. This turns on D302, mounted on the front panel. It serves as a power on indicator. When any one of the thermistors drops below the set level, transistor Q112 turns off. Now the current for D302 comes through D301, a flashing LED. Since this current is pulsing, D302 pulses along with D301. Once the PTC/thermistor cools, the voltage at the comparator goes above the trip point. The LED serves as a visual indicator of the trip condition of the PTC.

## POWER SUPPLIES

Power to the circuits is supplied by U103 +15V, U104 -15V, U101 +5V, and U102 -5V volt regulators.



# CALIBRATION PROCEDURE

## SECTION 2

### GENERAL

This instrument has been factory calibrated to the specifications set forth in this manual. However, after a period of use, the instrument may require recalibration as a result of component change or replacement.

Before attempting to calibrate this instrument, be sure the unit is operating properly, and that all malfunctions have been corrected. Refer to the Operation Manual to determine the operating conditions of the instrument.

Refer to Figure 5 for locations of calibrating controls.




FIGURE 5, Calibration Adjustments

### PRELIMINARY CALIBRATION PROCEDURE

1. Set all trimpots to mid position.
2. Turn the 1 kHz MOD and DC OFFSET switches OFF.
3. Push the TRIANGLE function button and the 1k FREQUENCY MULTIPLIER button in.



4. Set frequency dial to 10. Connect an oscilloscope to the HI OUTPUT.
5. Set the LEVEL control completely CW. Adjust R135 for 20 V<sub>P-P</sub> out.
6. Adjust R106 for symmetry. See Figure 6A.
7. Adjust R112 and R134 to center waveform at zero. See Figure 6B.
8. Press sine FUNCTION button in. Adjust R136 for 20 V<sub>P-P</sub> out. See Figure 6C. Adjust R147 to center waveform at zero.
9. Readjust R112, R134, R147 if necessary for best sine out.




FIGURE 6, Correct and Incorrect Waveshapes



## **FREQUENCY CALIBRATION**

### **A. 100 kHz**

1. Push the 100 k FREQUENCY MULTIPLIER button in and set the dial to 10.
2. Connect the Frequency Counter to the HI OUTPUT. Set GATE TIME to the 1 S position.
3. Adjust C114 for a reading on the counter of 900.000 to 1000.000.
4. Adjust C118 for a maximum signal amplitude out.
5. Adjust C114 for a reading of  $1000.000 \pm 010.000$ .
6. Set the dial to 5.
7. Adjust R133 for a reading of  $500.000 \pm 010.000$ .
8. Set dial to 1.
9. Adjust R164 for reading of  $100.000 \pm 010.000$ .
10. Set dial to 10.
11. Adjust R163 for reading of  $1000.000 \pm 0010.000$ .
12. Repeat steps 6 to 11 until all readings are within tolerance.

### **B. 1 kHz**

1. Push the 1 k button in.
2. Set the dial to 10.
3. Adjust R161 for reading of  $10.000 \pm .050$ .
4. Set the dial to 1.
5. Adjust R165 for reading  $1.000 \pm .050$ .
6. Repeat steps 2 to 5 until readings are within tolerance.
7. Set dial to 10 and a reading of  $10.000 \pm .050$ .

### **C. 100 HZ**

1. Push the 100 button in.
2. Adjust R160 for reading of  $1.000 \pm .005$ .

### **D. 10 HZ**

1. Push the 10 button in, and set the GATE TIME on the counter to the 10 S position.
2. Adjust R159 for a reading of  $.100 \pm .0005$ .

### **E. 1 HZ**

1. Push the 1 button in.
2. Adjust R158 for a reading of  $10 \pm .0002$ .



## **F. 10 kHz**

1. Push the 10K button in. Set the GATE TIME to the 1 S position.
2. Adjust R162 for a reading of  $100.000 \pm .500$ .

## **1kHz MOD.**


1. Set the LEVEL control to mid position. Connect the scope to HI OUTPUT.
2. Turn the 1 kHz Mod. switch ON.
3. Adjust R155 (500 ohm) for 50% modulation.
4. Connect the scope to EXT MOD. Check for 1 V<sub>P-P</sub> sine out.
5. Turn the 1 kHz Mod. switch OFF.

## **DC Offset**


Adjust R185 to center waveform at 0V.




# SCHEMATIC








BOTTOM VIEW



IC PIN DESIGNATION



NOTE: UNLESS OTHERWISE SPECIFIED, ALL RESISTORS ARE IN OHMS AND ALL CAPACITORS ARE IN MICROFARADS  
S1 POWER SWITCH MECHANICALLY ACTUATED BY AMPLITUDE ADJUST CONTROL



# TROUBLESHOOTING

## SECTION 3

Before troubleshooting any piece of equipment, the internal fusing should be checked. Because the wire within the fuse is not easily seen, an ohmmeter should be used to check for an open. This should be done with the fuse out of its holder.

The first thing to do after the power has been turned ON, is to check that all the DC supply voltages are present. Only after this has been determined should any troubleshooting be attempted.

Table 1 is intended to aid the service technician. Repair work, however, should not begin without a thorough knowledge of the circuit description given in this manual.

**TABLE 1**

PROBLEM	PROBABLE CAUSE	REPAIR TO BE DONE
NO FREQUENCY CONTROL	U109, Q106, U105	Isolate faulty component and replace
NO SINEWAVE OUT	U111, U112	Isolate faulty component and replace
NO TRIANGLE WAVE OUT	U110	Replace
NO SQUAREWAVE	U108, Q103, Q104, Q105	Isolate faulty component and replace
NO TTL OUT	U108, D101	Isolate faulty component and replace
NO MODULATION OR 1 KHZ SIGNAL OUT	Q107	Replace
LED WON'T LIGHT OR FLASH	U115, Q112, D301, D302	Isolate faulty component and replace
NO OUTPUTS WITH ANY FUNCTION SELECTED	Check inputs and outputs at U113 and U114. Isolate defective stage. Replace faulty component.	



# SERVICE PARTS LIST

## P.C. BOARD PARTS

### SCHEMATIC REFERENCE NUMBER

### PART NUMBER

### COMPONENT DESCRIPTION

U101  
U102  
U103  
U104  
U105, 107, 112  
U106, 110, 114  
U108  
U109  
U111  
U113  
U115

352-27805  
352-27905  
352-23415  
352-27915  
351-13080  
50313  
321-75107  
30055  
302-03039  
21614  
351-10339

### ICs

LM7805, +5 V Regulator  
LM7905, -5 V Regulator  
LM340T5, + 15 V Regulator  
LM7915, -15 V Regulator  
CA3080, Transconductance Op Amp  
CA3140, Op Amp  
75107, Dual Line Driver  
558, Dual Op Amp  
CA3039, Diode Array  
CA3086, Transistor Array  
LM339, Quad Comparator

Q101, 102  
Q103, 105, 107, 109  
Q104, 106, 108  
Q10  
Q111  
Q112

311-04434  
20845  
60131  
21048  
20824  
21510

### TRANSISTORS

D44C4, NPN  
2N3904, NPN  
2N3906, PNP  
D40D4, PNP  
D41D4, NPN  
MPS-A-13, Darlington NPN

BR101  
D101  
D102, 103  
D104, 105, 108-111,  
D116, 117  
D106, 107, 112-115,  
D118-123

20111  
30582  
38171  
21035  
20108

### DIODES

KBP-02, Bridge Rectifier  
1N4736, 6.8 V, 1 W Zener  
1N4746, 18 V, 1 W Zener  
1N914  
  
1N4002

C101, 132  
C102, 103  
C104, 105, 109, 111,  
C112, 120, 121,  
C129-131,  
C145-147, 153  
C106, 107, 110, 139  
C108  
C113, 140, 152  
C122  
C123

20631  
20912  
401-50103  
  
34202  
29109  
15133  
32117  
50239

### CAPACITORS

.1  $\mu$ F, 500 Disc.  
1000  $\mu$ F, 25 V Vert. Elect.  
.01  $\mu$ F, 50 V Disc.  
  
10  $\mu$ F, 50 V Vert. Elect.  
4.7  $\mu$ F, 16 V Vert. Elect.  
47 pF, 600 V Disc.  
470 pF, Disc.  
10  $\mu$ F, 35 V, 10% Tantalum

SCHEMATIC REFERENCE NUMBER	PART NUMBER	COMPONENT DESCRIPTION
C124	20629	4.7 $\mu$ F, 35 V, 10% Tantalum
C125	40519	1.5 $\mu$ F, 2%, 50 V Mylar
C126	40518	.15 $\mu$ F, 2%, 50 V Mylar
C127	40517	.015 $\mu$ F, 2%, 50 V Mylar
C128, 143	40516	.0015 $\mu$ F, 125 V, 2.5% Poly.
C134	15293	100 pF, 600 V Disc.
C136-138	462-10473	.047 $\mu$ F, 100 V Mylar
C142	not used	
C144	15295	.005 $\mu$ F, 600 V Disc.
C150, 151	29124	47 $\mu$ F, 50 V Vert. Electrolytic

#### POTENTIOMETERS

R106, 112, 147	29118	100 k Trimpot
R133, 158-160	33108	5 k Trimpot
R134, 185	29119	10 k Trimpot
R135, 161-163	32141	1 k Trimpot
R136	39532	2.5 k Trimpot
R155, 165	30024	500 Ohm Trimpot
R164	19617	250 Trimpot
R177	40656	2 k w/switch
R217	40655	10 k

#### RESISTORS

R101, 102	38630	1.2 k, 1/2 W, 5%
R103, 104, 116, 117, 124,	20645	1 k, 1/4 W, 5%
R130, 149, 151-153, 175		
R105, 111	60157	910 k, 1/4 W, 5%
R107	514-50622	6.2 k, 1/4 W, 5%
R108, 171	514-50822	8.2 k, 1/4 W, 5%
R109, 126	514-50182	1.8 k, 1/4 W, 5%
R110, 115, 118, 121,	50273	10 k, 1/4 W, 5%
123, 128, 129, 166,		
167, 209		
R113	514-50303	30 k, 1/4 W, 5%
R114, 180	514-50163	16 k, 1/4 W, 5%
R119, 120, 144, 145,	20656	100 Ohm, 1/4 W, 5%
R154, 190, 192, 206		
R122, 193, 195	20660	10 Ohm, 1/4 W, 5%
R125, 150, 173	20653	2.7 k, 1/4 W, 5%
R127	20651	1.2 k, 1/4 W, 5%
R131	16504	10 k, 2 W, 5%
R132	20424	27.4 k, 1/2 W, 1%
R137, 138, 141, 142	34213	47 k, 1/2 W, 5%
R139, 140, 172	15339	180 Ohm, 1/4 W, 5%
R143	15268	1 k, 1/2 W, 5%
R146	514-50473	47 k, 1/4 W, 5%
R148, 187, 188	20646	12 k, 1/4 W, 5%
R156	514-50183	18 k, 1/4 W, 5%



**SCHEMATIC  
REFERENCE  
NUMBER**

**PART  
NUMBER**

**COMPONENT  
DESCRIPTION**

R157	20655	3.9 k, 1/4 W, 5%
R168	60153	220 Ohm, 1/4 W, 5%
R169, 170, 179, 181, 182	20657	470 Ohm, 1/4 W, 5%
R174	20659	2.2 k, 1/4 W, 5%
R176	514-50152	1.5 k, 1/4 W, 5%
R191	514-50220	22 Ohm, 1/4 W, 5%
R183	514-15621	5.62 k, 1/4 W, 1%
R184	514-50133	13 k, 1/4 W, 5%
R186, 187	20859	2 k, 1/4 W, 5%
R194	514-05103	10 k, 1 W, 5%
R196-199	25512	10 Ohm, 1/2 W, 5%
R200	19614	820 Ohm, 1/2 W, 5%
R201, 202	543-05101	100 Ohm, 2 W, 5%
R203, 206	541-05470	47 Ohm, 1 W, 5%
R204, 205, 207, 208	514-50472	4.7 k, 1/4 W, 5%

R210, 212, 214	40673
R211, 213, 215	38134

**THERMISTORS**

Positive Temperature Coefficient  
Negative Temperature Coefficient

S101-105	40652A
S106A, 107-109, S106B	40653
	40620-01
	40058
	40027
	40672
	746-02037
	4200
	21054

**MISCELLANEOUS**

Pushbutton Switch Assembly, 9 Station  
Pushbutton Switch, 1 Station  
P.C. Board  
8 Pin I.C. Socket  
14 pin I.C. Socket  
Heat Sink Bracket  
6-32 x 3/8" PHMS/SEMS Type  
6-32 Hex Nut  
Shoulder Washer

D301	22970
D302	21640
R301	20652
	40620-11

**FLASHING LED BOARD PARTS**

Red Flashing LED CQX-21  
MV5054-1 LED  
33 Ohm, 1/4 W, 5%  
Flashing LED P.C. Board

F2	30583
R1	40654
S2, 3	22935
T1	40671
	40622C
	40677D
	40623
	40124
	40624

**CHASSIS PARTS**

**MISCELLANEOUS**

Fuse, 1/2 A  
Potentiometer, 2.5 k  
Toggle Switch  
Transformer  
Chassis  
Front Panel  
Dial  
BNC Connector  
Small Knob

**SCHEMATIC  
REFERENCE  
NUMBER**

**PART  
NUMBER**

**COMPONENT  
DESCRIPTION**

40510	Blue Pushbutton Knob
20112	Fuse Holder
15160	Terminal Strip
29020	Power Cord
748-02031	8-32 × 5/16" PHMS/SEMS Type
746-02025	6-32 × 1/4" PHMS/SEMS Type
20583	#8 Washer, 7/16; O.D.
746-02037	6-32 × 3/8" PHMS/SEMS Type
60196	Circuit Board Supports
736	Lockwasher, 3/8" Internal
4200	3/8"-32 Hex Nut
19164	4-36 × 3/8" BHMS
15175	4-36 × 3/16" Nut
18087	#4 Lockwasher
40678	Mica Washer
1599-10027	Tie Anchor Base
1599-00008	Tie Wrap
2460-90100	LED Hardware



## **WARRANTY**

ENERGY CONCEPTS, INC. warrants this equipment to be free from defective material and workmanship and agrees to remedy any such defect or to furnish a new part in exchange for any part of this unit which under normal installation, use, and service discloses such defect, provided that the unit is delivered by the purchaser to the dealer from whom purchased, or to Energy Concepts, Inc., or to a stipulated agent, intact, for the purpose of examination within a period of three years from the date of sale to the original purchaser and provided such examination discloses in our judgement that it is defective.

This warranty does not apply if the equipment has been subjected to misuse, neglect, improper installation, used in violation of instructions provided by us, or if repaired or in any way altered outside of our factory or authorized service facility, or if the serial number has been removed, defaced or changed.

Any part approved for remedy or exchange hereunder will be remedied or exchanged without charge to the owner.

Energy Concepts, Inc. assumes no liability for injury, damage, or expense claimed to have been incurred through the use or in the installation of our equipment and products.

This warranty is in lieu of all other warranties expressed or implied and no representative or person is authorized to assume for us any other liability in connection with the sale of this equipment.

Further information can be obtained from:

Energy Concepts, Inc.  
595 Bond Street  
Lincolnshire, Illinois 60069  
(847) 821-1900

ISBN 1-55756-062-5



9 781557 560629

PUBLISHED BY ENERGY CONCEPTS, INC., LINCOLNSHIRE, IL 60069

NO. 40608